

## Installing a glass shower screen onto Tilesafe Membrane - Timber floor

1. Apply a thin bead of RIW Polysulphide Joint Compound onto the bottom of the glazing profile, ensuring an additional amount is applied around the screw holes (*see Figure 1*)
2. Position the glazing channel onto the floor
3. Carefully screw into place, taking care when drilling the tiles to avoid any obstructions under the floor
4. Apply a skim coat of RIW Polysulphide Joint Compound over the screw heads (*see Figure 2*)
5. Install the glass screen

