



Wetroom waterproofing specification

Timber floors (small en-suite)

RIW Tilesafe membrane to be applied, in accordance with the manufacturer's recommendations, to the entire floor area.

Additional RIW Reinforcing Tape to be applied to all wall/wall junctions, soap recesses etc, within the shower area.

RIW FWM to be applied, in accordance with the manufacturer's recommendations, to the walls within the shower area finishing a minimum of 2 metres high and 300mm outside of the shower area in either direction, overlapping onto the Tilesafe membrane.

For steam rooms FWM should be applied full height to all walls.

Large timber floors and solid floors

RIW Tilesafe membrane to be applied, in accordance with the manufacturer's recommendations, to the floor area finishing a minimum of 1 metre outside the shower area in all directions. Additional RIW Reinforcing Tape to be applied to all wall/wall junctions, soap recesses etc, within the shower area.

RIW FWM to be applied, in accordance with the manufacturer's recommendations, to the walls within the shower area finishing a minimum of 2000mm high and 300mm outside of the shower area in either direction, overlapping onto the Tilesafe membrane.

For steam rooms FWM should be applied full height to all walls.

Available from:

CCL Wetrooms
Highview Business Park
The Barracks
Hook
RG27 9NL

T: 0844 3276002

E: enquiries@ccl-wetrooms.co.uk

W: www.ccl-wetrooms.co.uk